



# INSTALLATION MANUAL




#### Enerium 100 or 200

Rep.	Function
1.	LCD Screen
2.	Validation Key « OK »
3.	Optical head interface
4.	Navigation key

#### Enerium 100 / 200



Rep.	Function
1.	On-off or Analogue input / output
2.	Optical head interface
3.	Current inputs
4.	Voltage inputs
5.	RS485 communication interface
6.	Ethernet communication connection
7.	Power supply



## SAFETY

You have received a power monitor ENERIUM 100, 110, 200 or 210 and we thank you for your confidence.



To install this device with best conditions:

- Read this manual and the user's manual MS1-7352 (available on the CD enclosed with the box) and respect installation instructions specified in those two documents.
- This device is expected to be used in category III installations with a pollution degree of 2, in accordance with the standard IEC 61010-1.

## **INSTALLATION INSTRUCTIONS**

The device described in this manual is expected to be used only by authorized or trained users.

When the instrument is received, check that it is complete and has not been damaged during transport. In case of unsafe suspected on the product, it must be put out of order.

Before proceed to product electrical installation:

- Check that the power supply is disconnected and locked out in accordance with good practice and safety rules.
- Check that the network voltage and the required product voltage are the same


To be aware of others instructions, please consult the handbook MS1-7532 (Available on the CD enclosed with the box).

## **MECHANICAL INSTALLATION**

ENERIUM 100 or 200 have to be always installed on a panel. Proceed as follows:

- 1. Withdraw the four panel attachments. To withdraw a panel attachment, lift the front before sliding it. (figure 2)
- 2. Make a cut-out in the panel as shown by the figure 1
- 3. Insert the Enerium in the cut-out.

4. Slide the four panel attachments and push them until they hold the Enerium securely. (Figure 2)




The version without LCD can be installed on a DIN rail or in the back of a cabinet.. Proceed as follow:

1. Clip the two supports on the DIN rail (158mm centres between screws).

2. Attach the monitor to the two supports with screws (four different heights are possible). Figure 3

For the installation in back of cabinet, screw the power monitor directly to the back of the cabinet.



## **ELECTRICAL SPECIFICATIONS**


Voltage inputs	Un = 100V / 400 V
	Umax = 480 V
	Burden < 0,1 VA
Current inputs	In = 5 A
-	Imax = 6,5 A
	Burden < 0,15 VA
Auxiliary power supply	80 265 Vac (42,5 69 Hz) & 110 375 Vdc
	Consumption < 20 VA
	19,2 57,6 Vdc (Low level version)
	Burden $< 9 \text{ W}$
On-off inputs	10 70Vdc
-	Burden < 0,5W
On-off outputs	24 230Vac ±10%
_	24 110Vdc ±20%
	Burden ≤ 100mA
Analogue outputs	-20 mA ≤ Isortie ≤ 20 mA, avec Imax = 22mA
	Rmax ( $\Omega$ ) = 10V/Ioutput
	0,1 µF max
Analogue inputs	0 20 mA with Imax=22mA
	Rmax $(\Omega) = 50\Omega$
	Burden < 50mW


## **ELECTRICAL CONNECTIONS V & I**

The insertion of fuses on the voltage inputs and a system for shortcircuiting the current inputs is strongly recommended.

You will find below the mains wiring diagram on electrical network.


To be aware of the other wiring diagram, please consult the handbook MS1-7532 (Available on the CD enclosed with the box).






## **OPTIONAL CARDS WIRING**


#### ANALOGUE OUTPUTS



# ON-OFF INPUTS


(Pulses, alarm or synchronization)





ANALOGUE INPUTS

## **RS485 & ETHERNET CONNECTION**



1. Ethernet & RS485 options cannot be available simultaneously

2. For the RS485 network connection refer to standard in force

## **PARAMETERS LOCAL CONFIGURATION**

It has to be done through the configuration menu by selecting the icon beside and pressing the key  $O\!K$ 



Then in each menu, select the parameter to be modified with the keys  $\bigcirc$   $\bigcirc$  Then select the value to be modified with the key  $\bigcirc$   $\bigcirc$  Each value is modifiable with the key  $\bigcirc$   $\bigcirc$  Validate with key OK. Go back to the menu with the key  $\bigcirc$ 

In case of no action on keys during more than 3 minutes, the backlight is turned in standby mode.

ENERIUM 100, 110, 200 or 210 can be configured with the software E.Set supplied in each box. Communication with the product can be carried out localy with the optical head supplied in option or by remote control via RS485 (MODBUS RTU protocol) or Ethernet (MODBUS/TCP RTU).

Enerdis 16, rue Georges Besse Silic 44 92182 ANTONY Cedex - FRANCE Tel. : (33) 01 75 60 1030 Fax : (33) 01 46 66 62 54 info@enerdis.fr | www.enerdis.fr